

Nordco SP2R Dual Rail Spike Puller Critical Components

Critical for Propulsion	
Part Number	Description
96410050	Footswitch harness (dual side)
96450216	Footswitch harness (single side)
5128260	Foot switch
75108040	Sprocket
73045665	Bushing
5398885	Bearing
70900075	Brake shoe
50230093	Propulsion motor
75108001	Sprocket
73038566	Bushing
24262828	Drive chain
10061012	Addco throttle actuator
59427960	Pump
37750013	Destroke valve
28551843	Brake cylinder
68010027	Brake cylinder seal kit
42350007	Engine harness
520302	Engine harness (Cummins Tier 3)
500743	Propel valve
1623560	Cross-over relief
1605114	Make-up check valve

Critical for Operation	
Part Number	Description
1691103	Joystick valve
26600610	Controller
60570039	Oil cooler core
50211530	Oil cooler fan
5194800	Cooler temperature sender
18227711	Upper guide block
18227717	Lower guide block
28553587	Pulling cylinder (standard)
96090303	Pulling cylinder seal kit for 28553587
28554511	Pulling cylinder (Evergrip spike)
28550093	Spike claw cylinder
5195889	Control relay
5128935	Circuit breaker 10 amp
5128936	Circuit breaker 15 amp
5128937	Circuit breaker 20 amp
5128938	Circuit breaker 25 amp
5129889	Relay

IMPORTANT NOTE: These are general recommendations. Parts may vary based on the model and configuration of your machine. Consult Nordco Parts at 1-800-647-1724 for more information.



1-800-647-1724
www.nordco.com

© Nordco Inc. October 2010